



## SEATS

### VS10 ECO



**REF 101PM1078**  
foldable back  
non-suspension seat  
complete with runners

VS10 ECO + switch  
**REF 101PM1079**

### VS12 FOLDABLE



**REF 101PM1054**  
foldable back  
semi--suspension seat  
complete with runners

### VS12



**REF 101PM3232**  
back rest and weight adj.  
suspension seat  
complete with runners

VS12 + switch  
**REF 101PM4259**

### ES12



**REF 101PM1660**  
back rest and weight adj.  
suspension seat  
complete with runners


ES12 + switch  
**REF 101PM3145**

### KAB 211



**REF 101PM3233**  
suspension seat  
weight, cushion  
& back adjustment  
complete with runners

### GRAMMER MSG20



**REF 101PM1613**  
suspension seat  
weight, front/rear  
& back adjustment  
with seat belt brackets

### UNIVERSAL SEAT



**REF 101PM1900**  
Universal  
non-suspension seat  
complete  
with runners

### SEAT



**REF 101PM1899**  
Foldable back  
non-suspension seat  
complete with  
runners

### NARROW ECO SEAT



**REF 101PM4258**  
Foldable back  
non-suspension seat  
complete with  
runners

ORDER REF	description
101PM1078	VS10 eco
101PM1079	VS10 eco + switch
101PM1054	VS12 • foldable seat
101PM3232	VS12
101PM4259	VS12 + switch
101PM1660	ES 12
101PM3145	ES12 + switch
101PM3233	KAB 211
101PM1613	Grammer MSG 20
101PM1900	universal seat
101PM1899	seat
101PM4258	Narrow Eco Seat